

Online practice lab assignment (III)
Course code : CSE - 406
Course Name : Digital image processing
Laboratory

Name: Abdul Mukit

Roll : 2407

Exam Roll: 170491

Session : 2018 -19

Submitted to
Prof. Dr. Liton Jude Rojario
Department of Computer Science and
Engineering
Jahangirnagar University.

Exp:01 Read and display digital images
with python, scilab and matlab

Python code

```
import skimage.io as io
import matplotlib.pyplot as plt

gray_img = io.imread('Cameraman.tif')
color_img = io.imread('color.tif')
indexed_img = io.imread('indexed.png')

plt.subplot(1,3,1)
plt.imshow(gray_img, cmap="gray")
plt.subplot(1,3,2)
plt.imshow(color_img)
plt.subplot(1,3,3)
plt.imshow(indexed_img)
plt.show()
```


Matlab code

```
gray-img = imread ('cameraman.tif');  
color-img = imread ('color.tif');  
indexed-img = imread ('indexed.png');
```

```
subplot (1,3,1);
```

```
imshow (gray-img);
```

```
subplot (1,3,2)
```

```
imshow (color-img)
```

```
subplot (1,3,3)
```

```
imshow (indexed-img)
```

Exp: 02 Visualize image histogram and perform histogram equalization with python

```
>>> import matplotlib.pyplot as plt
import skimage.io as io
import cv2
import skimage.exposure as ex
img01 = io.imread('cameraman.tif')
eq_img = cv2.equalizeHist(img01)
plt.subplot(1,3,1)
plt.imshow(img01, cmap='gray')
plt.subplot(1,3,2)
plt.imshow(eq_img, cmap='gray')
plt.subplot(1,3,3)
plt.hist(img01.flatten(), bins=256)
plt.show()
```



```

# RGB image
img2 = io.imread('colon.tif')

r_channel = img2[:, :, 0]
g_channel = img2[:, :, 1]
b_channel = img2[:, :, 2]

plt.subplot(1, 5, 1)
plt.imshow(img2)
plt.subplot(1, 5, 2)

plt.hist(r_channel.flatten(), bins=256)

plt.subplot(1, 5, 3)
plt.hist(g_channel.flatten(), bins=256)

plt.subplot(1, 5, 4)
plt.hist(b_channel.flatten(), bins=256)

Ihsv = color.rgb2hsv(img2)
v = ex ex.equalize_hist(Ihsv[:, :, 2])
Ihsv[:, :, 2] = v

eq_img2 = color.hsv2rgb(Ihsv)
plt.subplot(1, 5, 5)
plt.hist(eq_img2.flatten(), bins=256)
plt.show()

```

Exp: 03 : Filtering an image with python (Gaussian, Laplacian)

```

=> import numpy as np
import skimage.io as io
import scipy.ndimage as ndi
import matplotlib.pyplot as plt
img01 = io.imread('cameraman.tif')
img02 = ndi.gaussian_filter(img01, 1, truncate=1)
laplacian_filter = np.array([[0, 1, 0], [1, -4, 1],
                             [0, 1, 0]])
img03 = ndi.convolve(img01, laplacian_filter,
                    mode='constant')
plt.subplot(1, 3, 1)
plt.imshow(img01, cmap='gray')
plt.subplot(1, 3, 2)
plt.imshow(img02)
plt.subplot(1, 3, 3)
plt.imshow(img03)
plt.show()

```


Exp:4 Transforming an image with python

① FFT ② DWT

```
import skimage.io as io
from skimage.color import rgb2gray
import numpy as np
import matplotlib.pyplot as plt
import pywt
img = io.imread('comeraman.tif')
dft = np.fft.fft2(img)
dft_shift = 20 np.fft.fftshift(dft)
dft_result = 20 * np.log(np.abs(dft_shift))

plt.subplot(1,2,1)
plt.imshow(img)
plt.subplot(1,2,2)
plt.imshow(dft_result)
plt.show()
```

DWT

coeffs = pywt.dwt2(img, 'haar')

CA, (CH, CV, CD) = coeffs

plt.subplot(2,2,1)

plt.imshow(img)

plt.subplot(2,2,2)

plt.imshow(~~A~~, CA)

plt.subplot(2,2,3)

plt.imshow(CH)

plt.subplot(2,2,4)

plt.imshow(CV)

plt.show()

Exp: 5 performing segmentation on image
with python ① Thresholding
② edge detection

```

=> import skimage.io as io
import numpy as np
import matplotlib.pyplot as plt
from skimage import filters
img1 = io.imread('comenaman.tif')
r, c = img1.shape
x, y = np.mgrid[0:r, 0:c].astype('float')
p2 = 255.0 - img1 + y/2
plt.subplot(1, 3, 1)
plt.imshow((img1 > 40) & (img1 < 30), cmap='gray')
plt.subplot(1, 3, 2)
plt.imshow(img1 > 40, cmap='gray')
plt.subplot(1, 3, 3)
plt.imshow(p2)
plt.show()

```


edge detection

edge-p = filters.prewitt (img1)

edge-n = filters.roberts (img1)

edge-s = filters.sobel (img1)

plt.subplot (1,3,1)

plt.imshow (edge-p, cmap = 'gray')

plt.subplot (1,3,2)

plt.imshow (edge-n, cmap = 'gray')

plt.subplot (1,3,3)

plt.imshow (edge-s, cmap = 'gray')

plt.show ()

Exp: 6 Restoring images from noises with

Python . ① Salt & pepper noise

② periodic noise

⇒ import skimage.io as io

import numpy as np

import matplotlib.pyplot as plt

import skimage.util as util

import scipy.ndimage as ndi

from numpy.fft import fftshift, fft2, ifft2, ifftshift


```

import skimage.exposure as ex
sp = io.imread('img1.tiff')
gp = io.imread('img2.tiff')
img-med = ndi.median-filter(sp, 3)
gf = fftshift(fft2(sp))
mg-spectrum = np.abs(gf)
temp = ex.rescale_intensity(abs(gf), out-range
                             = (0, 1))
gf2 = util.img_as_byte(temp)
i,j = np.where(gf2 == gf2.max())
Z = np.sqrt((x-512)**2 + (y-512)**2)
k = 1
d = np.sqrt(5832)
br = (7 < np.floor(d-k) | (Z > np.ceil(d+k)))
gfr = gf * br
filtered_gp = np.real(fft2(fftshift(gfr)))
plt.subplot(1,2,1)
plt.imshow(img-med, cmap='gray')
plt.subplot(1,2,2)
plt.imshow(filtered_gp, cmap='gray')
plt.show()

```

Exp. 07 perform morphological processing
 → of images (dilation & erosion)

import skimage.io as io

import numpy as np

from skimage.filters import threshold_otsu

from skimage.color import rgb2gray

from scipy.ndimage import binary_erosion,
 binary_dilation

bw = io.imread('text.png')

se1 = np.ones((4,4), dtype=bool)

se2 = np.array([[0,0,0,0,0]

[0,0,0,0,0]

[0,0,1,0,0]

[0,0,0,0,0]

[0,0,0,0,0]])

bw1 = binary_dilation(bw, structure=se1)

bw2 = binary_erosion(bw, structure=se2)

plt.subplot(1,2,1)

plt.imshow(bw1)

plt.subplot(1,2,2), plt.imshow(bw2)

plt.show()

Exp: 08 processing colon images with python

① Converting RGB to HSV / HSI

② Separate RGB channels

⇒

```
import numpy as np
```

```
import matplotlib.pyplot as plt
```

```
from skimage import io, color
```

```
img = io.imread('colon.tiff')
```

```
hsv_img = color.rgb2hsv(img)
```

```
lab_img = color.rgb2lab(img)
```

```
r_channel = img[:, :, 0]
```

```
g_channel = img[:, :, 1]
```

```
b_channel = img[:, :, 2]
```

```
plt.subplot(2, 3, 1)
```

```
plt.imshow(hsv_img)
```

```
plt.subplot(2, 3, 2)
```

```
plt.imshow(hsi_img)
```

```
plt.subplot(2, 3, 3)
```

```
plt.imshow(lab_img)
```

```
plt.subplot(2, 3, 4)
```

```
plt.imshow(r_channel)
```

```
plt.subplot(2,3,5)
plt.imshow(g_channel)
plt.subplot(2,3,6)
plt.imshow(b_channel)
plt.show()
```

Exp: 10 miscelence ~~pop~~ topic in image processing

- ① special effect
- ② video processing

```
① import numpy as np
import skimage.io as io
import skimage.color as color
import matplotlib.pyplot as plt
f = io.imread('iris1.png')
fg = color.rgb2gray(f)
rows, cols = fg.shape
y, x = np.mgrid[0:cols, 0:rows]
z2 = clip(x + x * 0.32, 0, rows - 1)
```



```
ripple2 = np.reshape (fg[x.ravel(), y2.ravel()]
                        (rows, cols)).T)
```

```
ripple3 = np.reshape (fg[x2.ravel(), y2.ravel()]
                        (rows, cols)).T)
```

```
r, theta = cart2polar (x, y)
```

```
r2 = r + np.mod (r, 30)
```

```
ripple4 = polar2im (fg, r2, theta)
```

```
plt.subplot (2, 2, 1)
```

```
plt.imshow (ripple1)
```

```
plt.subplot (2, 2, 2)
```

```
plt.imshow (ripple2)
```

```
plt.subplot (2, 2, 3)
```

```
plt.imshow (ripple3)
```

```
plt.subplot (2, 2, 4)
```

```
plt.imshow (ripple4)
```

```
plt.show()
```

```

① import numpy as np
import cv2 as cv
import scipy.ndimage as ndi
cap = cv.VideoCapture('cat.mp4')
angle = 0
cap.set(cv.CAP_PROP_FRAME_WIDTH, 256)
cap.set(cv.CAP_PROP_FRAME_HEIGHT, 144)

if not cap.isOpened():
    print("cant open video file")
    exit()

```

while True :

```
ret, frame = cap.read()
```

```
if not ret:
```

```
    print("cant receive frame. Exiting...")
```

```
    break
```

```
cv2.imshow('original video', frame)
```

```
gray = cv.cvtColor(frame, cv.COLOR_BGR  
                2GRAY)
```

```
cv.imshow('grayscale video', gray)
```


$angle = (angle + 1) \cdot 1.360$

$output = ndi.rotate(frame, angle, reshape = false)$

$cv.imshow('Rotate FRAME', output)$

$if\ cv.waitKey(1) == 27:$

$break$

$cap.release()$

$cv.destroyAllWindows()$